

Growth of large diameter high-purity germanium crystals for Nuclear Physics research

Principal Investigator: Richard Pehl, Ph.D.
Presented by Ethan Hull, Ph.D.

DE-SC0004256


Phase II: 8/15/11-8/14/13

Extremely large diameter (150-200 mm) high-purity germanium crystals are being developed for large diameter Nuclear Physics planar detectors. A high-purity germanium crystal puller has been demonstrated to grow crystals having sufficient purity and charge-collection properties to produce detector-quality germanium. The puller has the capacity to grow very large diameter (~ 200 mm) germanium crystals.

The diameter of the germanium crystals and purity levels are being iteratively improved. The results are being constantly monitored through test detector fabrication and gamma-ray spectroscopy measurements.

Collaboration with Kim Lister at UMass Lowell


- Material Processing and Crystal Growth at PHDs Co.
- Crystal Measurements and Properties
 - Large diameter challenges
 - Impurity concentration and doping
 - Charge collection
- Products – Nuclear Physics is the basis



PHDs Co. 3011 Amherst Rd, Knoxville, TN www.phdsco.com

- **Germanium Detector Systems**
 - **Concept**
 - **Germanium refinement and crystal growth**
 - **Mechanical-Vacuum-Cryogenic Engineering**
 - **Detector Fabrication**
 - **System Integration**
 - **Information output**
- **Est. Fall 2004, Ethan Hull CEO, Richard Pehl CFO**
- **9 FTEs + 2-3 Consultants – Technical Emphasis**
- **PHDs Co. sells germanium detector system products**
 - **Nuclear Physics - NPX-M**
 - **Security Applications - GeGI and SPG**
 - **Nuclear Medicine - MIX**





PHDs Co.



10,000 ft² Facility
Knoxville, TN




Technical area (~ 8000 ft²)



Office area (~ 2000 ft²)



Goal: make significantly larger diameter detector systems




Summary of Accomplishments

- Solved some large-diameter challenges $\sim N(r)$
- Lowered Impurity concentration to tolerable levels
- Established a viable doping method
 - Sources of contamination
- Improved understanding of trapping
- **Doubled the mass and area of the crystals!!!!**

NPX-M

Material Processing and Crystal Growth at PHDs Co.


PHDs
Co.



Electronic Grade Ge or CZ remelt



High Purity Zone refinement, SiO₂, H₂




High Purity CZ Puller, SiO₂, H₂




Evaluation

Detectors





PHDs
Co.




**10 kg HP ZR Ge
In the puller**


PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.




PHDs
Co.





PHDs
Co.





PHDs
Co.





PHDs
Co.









PHDs
Co.





PHDs
Co.





PHDs
Co.







PHDs
Co.





PHDs
Co.














Material Processing and Crystal Growth at PHDs Co.

PHDs
Co.



**Increased the crystal diameter from 90 mm to 140 mm
Area increased by a factor of 2 !!!!**





122 keV
FWHM = 1.05 keV
FWTM = 2.03 keV


Detector #2
Slice #3
Crystal 41012

Fano Factor:
 $[FWHM]_{Detector} = 2.355\sqrt{\epsilon FE}$

Fano Factor
FWHM = 0.11
FWTM = 0.10


662 keV
FWHM = 1.44 keV
FWTM = 2.69 keV

**At this level the Fano factor is a
measure of trapping**



Impact of Larger Diameter Crystals

PHDs
Co.




Germanium Gamma-ray Imager (GeGI) for Security Applications



If Germanium Crystal Diameters increase from 90 mm to 200 mm → GeGI becomes ~10x more sensitive for SNM detection.

Impact of Larger Diameter Crystals

PHDs
Co.



New Germanium Gamma Cameras for Nuclear Medicine

